



Pneumatic Tire Maintenance

1. Check all 4 Nuts and Bolts on hub(s) and tighten regularly (if applicable).
2. Do NOT inflate if bolts are missing.
3. Check pneumatic tires for proper PSI.
4. USE HAND PUMP ONLY TO INFLATE TIRES
5. **WARNING** – Over inflation or the use of electronic air pumps/compressors may result in damage to the tire/wheel and could cause serious bodily injury.

Entretien pneumatique des pneus

1. Vérifier tous les 4 écrous et boulons de concentrateurs et serrer régulièrement (le cas échéant).
2. Ne gonflez pas s'il manquants des boulons.
3. Recherchez pneus bon lb/po2.
4. UTILISER LA POMPE À MAIN UNIQUEMENT POUR GONFLER LES PNEUS
5. **AVERTISSEMENT** – un gonflement excessif ou l'utilisation de pompes à air électroniques/compresseurs peut-être causer des dommages à l'ensemble pneu/roue et pourrait causer des blessures graves.

Mantenimiento de llantas neumáticas

1. Compruebe los 4 tornillos y tuercas en cubo (s) y apriete regularmente (si es aplicable).
2. No infle si faltan tornillos.
3. Revise los neumáticos para una correcta PSI.
4. USE LA BOMBA DE MANO SOLAMENTE PARA INFLAR LOS NEUMÁTICOS
5. **ADVERTENCIA:** la sobreinflación o el uso de bombas / compresores de aire electrónicos pueden dañar el neumático / rueda y causar lesiones corporales graves.